




# TOP AND CONSOLE PARTS

ELECTRIC DRYER

For Models: LER6634BW2, LER6634BN2, LER6634BQ2  
(White) (Almond) (Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# TOP AND CONSOLE PARTS

For Models: LER6634BW2, LER6634BN2, LER6634BQ2  
(White) (Almond) (Designer White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3397545	Panel, Rear Console	13	688983	Screw, 8-18 x 5/8	39	3395382	Switch, Push-To-Start 692021 (Alt.)
2	3396028	Wire Jumper Assembly	14	3353145	Screw, Console	48	3396145	Timer Knob & Dial Assembly
3	693995	Screw, Hex Head	15	3354281	Switch, Temperature Top		3396146	FOR MODEL LER6634BQ1
4	3358531	White Cap, End (L.H.)	16	3396022	White	53	3396293	Bracket, Control Panel, Control
	3358532	Almond		3396023	Almond	54	3397205	FOR MODEL LER6634BW1
5	3390647	Screw, 8-18 x 1/2	17	693995	Screw, Hex Washer Head		3397206	FOR MODEL LER6634BN1
6	357213	Stop, Push-In	18	3358431	Knob, Temperature Control		3397207	FOR MODEL LER6634BQ1
7	3388706	Resistor		3358435	FOR MODEL LER6634BQ1	62	688805	Clip
8	689180	Clip, Retainer	19	3397269	Connector, Timer	72	690853	Wire, Ground
9	3358516	White Cap, End (R.H.)	20	3347243	Connector (6-Circuit)	81	3396160	Knob, Push To Start
	3358517	Almond	21	3392250	Timer 60 Hz.		3396161	FOR MODEL LER6634BQ1
10	339392	Screen, Lint	22	3395683	Connector (Motor)			
11	688150	White Cover, Lint Screen	23	3394427	Clip-Harness			
	689310	Almond	29	3390646	Screw, 8-18 x 5/16			
12	339229	Hinge, R.H.	31	3399659	Harness, Wiring			
	339230	Hinge, L.H.						


## LITERATURE AND OPTIONAL PARTS

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
<b>LITERATURE PARTS</b>			<b>OPTIONAL PARTS NOT INCLUDED</b>					
LIT3401083		Guide, Use & Care	<b>PAINT, TOUCH-UP (1/2oz.)</b>			<b>PAINT, BULK (1 qt.)</b>		
LIT3397597		Instructions, Installation	72017		White	799344		White (Uncut)
LIT3401728		Label, Wiring Diagram	72107		Almond	978883		Almond (Uncut)
			<b>PAINT, PRESSURIZED SPRAY (13 oz.)</b>			<b>Following May Be Purchased</b>		
			350930		White	<b>DO-IT-YOURSELF REPAIR MANUALS</b>		
			350956		Almond	LIT677818		Dryer
			350938		Primer, Gray			
			350941		Leveler (Thinner)			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS

For Models: LER6634BW2, LER6634BN2, LER6634BQ2  
(White) (Almond) (Designer White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS


For Models: LER6634BW2, LER6634BN2, LER6634BQ2  
(White) (Almond) (Designer White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
2	343641	Screw, 10–16 x 1/2	19	98234	Clip, Ground (2)	38	349464	Seal & Bearing Assembly
4	238614	Bumper	20	690363	Lock, Front Top (2)	40	3393008	Screw
5	3396795	Cover, Terminal Block	21		Panel Assembly, Upper Front	41	690261	Block, Terminal
6	342043	Screw, 10–32 x 1/2		338012	White	42	279393	Terminal Block Kit For
7	3396807	Panel, Rear		689533	Almond			Terminal Block
10	347207	Switch, Door	22	693994	Screw, Hex Washer Head (7)	48	297092	Clip, Hinge (2)
11	98129	Screw, 6–20 x 7/8 (2)	23	685203	Clip, Felt Pad (2)	49		Panel, Toe
13	3357011	Screw, 10–16 x 1/2	24	690081	Catch, Door		692427	White
14	237979	Spring, Door (2)	26	337189	Clip, Hinge (2)		692428	Almond
15	3388229	Clip, Toe Panel (2)	27	694091	Screw (6)	51	238088	Hinge, Top (2)
16	3392100	Foot	28	687905	Hinge, R.H.	53	691366	Idler & Pulley Assembly
	279810	Foot–Optional (Extended Length Package of 2 Not Included.)	29	279318	Terminal, Tinned & Brass (3) (Includes Illus. 42)	56	660996	Belt, Drive
17	691581	Lever, Door Switch	31	98997	Clip, Harness	57	348780	Base, Motor
18		Cabinet	33	696144	Strike, Door	58	172455	Bolt, 5/16–18 x 3/4
	3399580	White	35	695954	Door, Rear	59	3401143	Pulley, 60 Hz.
	3399581	Almond (Includes Illus. Nos. 5,7,16,41, And 58.)	36		Door, Front	62	3395652	Motor Assembly, 60 Hz.
				348728	White	63	660658	Clip, Motor (2)
				689330	Almond			343481 (Alt.)
			37		Handle, Door			685441 (Alt.)
				690270	White	67	3390733	Seal, Door
				690271	Almond	87	697776	Screw, 10–32 x 1/2 (Grounding)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BULKHEAD PARTS

For Models: LER6634BW2, LER6634BN2, LER6634BQ2  
(White) (Almond) (Designer White)



Illus. No.	Part No.	DESCRIPTION
1	694283	Lint Chute Assembly
4	3392247	Pad, Cabinet (Blower Housing)
5	90767	Screw, 8 x 3/8
6	3387134	Thermostat, Internal-Bias
7	3399848	Thermal Cut-Off (Hi-Limit Thermostat Illus. No. 15 Included)
8	3392519	Thermal Fuse
9	3388703	Washer, Support
10	694089	Wheel, Blower (Includes Illus. No. 19)
11	348013	Housing, Blower

Illus. No.	Part No.	DESCRIPTION
12	3398161	Clip
13	343641	Screw, 10-16 x 1/2
14	3397566	Box, Heater
15	3390291	Thermostat, 250°F (121.1°C)
16	3400800	Screw, 8-18 x 3/4
17	3398064	Element, Heater (For 240 Volt Installation)
18	279457	Wire Kit (For Heater Element Wiring Harness Repair)
19	3392123	Seal, Blower
20	90767	Screw, 8-18 x 3/8

Illus. No.	Part No.	DESCRIPTION
24	347139	Seal, Lint Chute
41	690997	Ring, Tri
42	3399506	Shaft, L.H.
43	3399507	Shaft, R.H.
44	3397588	Roller, Support
46	348197	Washer Support
47	3359452	Nut, 3/8-16
48	3397264	Bulkhead
62	3394509	Ring, Bearing
63	97787	Screw, 11-16 x 7/8
66	337449	Seal, Rear Drum
67	3396777	Drum Assembly
68	342847	Baffle, Drum
69	3394133	Bracket, Support
70	90296	Clip
73	339956	Seal
75	696302	Shield, Exhaust

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST